

let's have some fun

Ecoo's products are very easy to install. Just follow these simple step-by-step guidelines and you'll be enjoying your new garden faster than you think. If you need more instructions, find a full instructional video on our YouTube channel. Type in 'Ecolat' and we'll help you on your way!

Garden edging



Place the Ecolat along the desired edge line. Rolled-up Ecolat will naturally unroll once laid out.

Dig a shallow trench and place the Ecolat inside it, ideally burying at least two-thirds of it below ground level.

Use a rubber mallet to drive the Ecopic posts into the ground. The H-profile ensures excellent stability. The top of each post should sit about 3 cm below the top edge of the Ecolat, making them invisible once installation is complete. Depending on the application, place a post at least every 50 cm.

Secure the Ecolat to the Ecopic posts using stainless steel screws—two per post. A spirit level can help ensure a straight and even result.

Finally, fill the outside of the garden border with soil, wood mulch, stones, or other materials as desired.

Simply create your own pond

Tap the Ecopic posts into the ground and roll out the Ecolat and place it in front of the Ecopics.

Use a spirit level for an even result and determine the maximum water level of your pond.

Place a protective membrane in the pond and over the edge of the Ecolat. This membrane protects the pond liner from friction and sharp objects in the ground.

Place the pond liner so that it also reaches over the edge of the border and finish neatly at the outer edge.

